

HAFELE UTENSIO

HU Slide Corner




Reference codes


549.00.121
549.00.122
549.00.123
549.00.124

549.00.125
549.00.126
549.00.127
549.00.128


LH



RH




A



x 1

B



x 1

Guarantee and T&Cs apply.


Follow the instructions carefully, failing to adhere to the instructions or modifying the product will invalidate the guarantee.

Clean and Maintenance

Scan the QR code to discover the correct way to dispose the packing and the correct maintenance of the product.






C



x 1

E / F / G / H


x 3 x 3 x 3 x 17



COD: 0536

Only for M400 / M450 / M500





D



x 1

E / F / G / H / I


x 3 x 3 x 3 x 17 x 1



COD: 0555

Only for M600

J






x 1





Häfele SE & Co KG
Adolf-Häfele-Str. 1
72202 Nagold
Germany
info@haefele.de www.haefele.com



TECHNICAL INFORMATION




	X1	X2
M400	≥ 755	≥ 350
M450	≥ 840	≥ 400
M500	≥ 895	≥ 450
M600	≥ 935	≥ 550




1. Example: M450







x 1




x 8



x 1



2. 



B




x 1

G




x 3





H  PZ2
16
x 9
Ø4 x 16











3. 




4. 




1. (LH) Example: M450



x 1



x 8



x 1



2. **LH**



B



x 1

G

x 3




H  PZ2
16
x 9
Ø4 x 16




1





x 1




3. (LH)




4.



RH



LH



(RH)

Dimension for CNC

(LH)

